

TOLERANCE IN MATH

THE ROLE OF TOLERANCE IN MATHEMATICAL PRECISION

TOLERANCE IN MATH IS A FUNDAMENTAL CONCEPT THAT ADDRESSES THE INHERENT IMPRECISION IN MEASUREMENT AND CALCULATION, ACKNOWLEDGING THAT PERFECT ACCURACY IS OFTEN AN UNATTAINABLE IDEAL. WHETHER WE ARE DEALING WITH ENGINEERING SPECIFICATIONS, SCIENTIFIC EXPERIMENTS, OR EVEN EVERYDAY ESTIMATIONS, UNDERSTANDING AND QUANTIFYING ACCEPTABLE DEVIATIONS IS CRUCIAL FOR PRACTICAL APPLICATIONS. THIS ARTICLE WILL DELVE INTO THE MULTIFACETED WORLD OF TOLERANCE IN MATHEMATICS, EXPLORING ITS DEFINITION, VARIOUS APPLICATIONS, HOW IT'S REPRESENTED, AND ITS VITAL IMPORTANCE IN ENSURING THE FUNCTIONALITY AND RELIABILITY OF SYSTEMS AND PRODUCTS ACROSS NUMEROUS FIELDS. WE WILL UNCOVER WHY A LITTLE WIGGLE ROOM IS NOT ONLY ACCEPTABLE BUT OFTEN ESSENTIAL FOR MATHEMATICAL PROCESSES TO REMAIN MEANINGFUL AND ACTIONABLE IN THE REAL WORLD.

TABLE OF CONTENTS

WHAT IS MATHEMATICAL TOLERANCE?

WHY IS TOLERANCE NECESSARY IN MATH?

TYPES OF TOLERANCE IN MATHEMATICS

TOLERANCE IN MEASUREMENT AND ENGINEERING

TOLERANCE IN NUMERICAL ANALYSIS AND COMPUTATION

TOLERANCE IN GEOMETRY AND DESIGN

CALCULATING AND EXPRESSING TOLERANCE

THE IMPORTANCE OF UNDERSTANDING TOLERANCE

WHAT IS MATHEMATICAL TOLERANCE?

AT ITS CORE, MATHEMATICAL TOLERANCE REFERS TO THE PERMISSIBLE RANGE OF VARIATION OR DEVIATION FROM A SPECIFIED VALUE, DIMENSION, OR STANDARD. IT'S ESSENTIALLY A WAY TO DEFINE AN ACCEPTABLE MARGIN OF ERROR. INSTEAD OF DEMANDING AN EXACT, PINPOINT FIGURE, TOLERANCE ALLOWS FOR A ZONE WITHIN WHICH A MEASUREMENT OR CALCULATION IS CONSIDERED SATISFACTORY AND FUNCTIONAL. THINK OF IT AS A BOUNDARY, A LIMIT THAT DEFINES WHAT IS "CLOSE ENOUGH" FOR PRACTICAL PURPOSES. THIS CONCEPT IS NOT ABOUT INACCURACY FOR ITS OWN SAKE, BUT RATHER A PRAGMATIC APPROACH TO DEALING WITH THE LIMITATIONS OF TOOLS, HUMAN CAPABILITIES, AND THE INHERENT VARIABILITY OF THE PHYSICAL WORLD.

IN MATHEMATICAL TERMS, TOLERANCE CAN BE EXPRESSED AS A PLUS-AND-MINUS VALUE (E.G., 5 ± 0.2) OR AS A RANGE (E.G., BETWEEN 4.8 AND 5.2). THIS RANGE SIGNIFIES THE UPPER AND LOWER LIMITS WITHIN WHICH A GIVEN QUANTITY IS DEEMED ACCEPTABLE. WITHOUT TOLERANCE, MANY REAL-WORLD APPLICATIONS WOULD BE IMPOSSIBLE TO ACHIEVE, AS ABSOLUTE PRECISION IS OFTEN ECONOMICALLY UNFEASIBLE OR PHYSICALLY IMPOSSIBLE TO ATTAIN.

WHY IS TOLERANCE NECESSARY IN MATH?

THE NECESSITY OF TOLERANCE IN MATHEMATICS STEMS FROM SEVERAL KEY FACTORS. FIRSTLY, THE LIMITATIONS OF OUR MEASURING INSTRUMENTS PLAY A SIGNIFICANT ROLE. NO RULER, CALIPER, OR DIGITAL SENSOR CAN MEASURE WITH INFINITE PRECISION. THERE WILL ALWAYS BE A SMALLEST INCREMENT OF MEASUREMENT, AND THE ACTUAL VALUE COULD LIE ANYWHERE WITHIN THAT INCREMENT. SECONDLY, MANUFACTURING PROCESSES, EVEN HIGHLY SOPHISTICATED ONES, INTRODUCE VARIATIONS. IT'S INCREDIBLY DIFFICULT AND EXPENSIVE TO PRODUCE TWO IDENTICAL PARTS, FOR EXAMPLE. TOLERANCE ENSURES THAT PARTS CAN STILL BE ASSEMBLED AND FUNCTION CORRECTLY EVEN WITH MINOR DIFFERENCES.

FURTHERMORE, HUMAN ERROR, THOUGH MINIMIZED THROUGH RIGOROUS PROCEDURES, CAN ALSO LEAD TO DEVIATIONS. IN SCIENTIFIC EXPERIMENTATION, EXPERIMENTAL CONDITIONS ARE RARELY PERFECTLY CONSTANT, LEADING TO VARIATIONS IN COLLECTED DATA. IN COMPUTATIONAL MATHEMATICS, ROUNDING ERRORS CAN ACCUMULATE, AND TOLERANCE IS USED TO

DETERMINE WHEN A NUMERICAL SOLUTION IS SUFFICIENTLY CLOSE TO THE TRUE SOLUTION. ESSENTIALLY, TOLERANCE PROVIDES A PRACTICAL BRIDGE BETWEEN THEORETICAL PERFECTION AND THE REALITIES OF THE PHYSICAL AND COMPUTATIONAL WORLDS, ENSURING THAT MATHEMATICAL MODELS AND THEIR APPLICATIONS REMAIN RELEVANT AND FUNCTIONAL.

TYPES OF TOLERANCE IN MATHEMATICS

MATHEMATICAL TOLERANCE CAN MANIFEST IN VARIOUS FORMS DEPENDING ON THE CONTEXT. UNDERSTANDING THESE DISTINCTIONS IS KEY TO APPLYING THE CONCEPT EFFECTIVELY. WHILE THE UNDERLYING PRINCIPLE OF AN ACCEPTABLE RANGE REMAINS, THE WAY THIS RANGE IS DEFINED AND UTILIZED CAN DIFFER SIGNIFICANTLY.

ABSOLUTE TOLERANCE

ABSOLUTE TOLERANCE IS PERHAPS THE MOST STRAIGHTFORWARD TYPE. IT INVOLVES A FIXED NUMERICAL VALUE THAT REPRESENTS THE MAXIMUM ALLOWABLE DEVIATION FROM A TARGET VALUE. FOR INSTANCE, IF A COMPONENT NEEDS TO BE 100 MM LONG WITH AN ABSOLUTE TOLERANCE OF ± 1 MM, THEN ANY LENGTH BETWEEN 99 MM AND 101 MM IS ACCEPTABLE. THIS IS COMMONLY SEEN IN SPECIFICATIONS FOR STANDARDIZED PARTS OR DIMENSIONS WHERE CONSISTENCY IS PARAMOUNT.

PERCENTAGE TOLERANCE

PERCENTAGE TOLERANCE IS OFTEN USED WHEN THE ACCEPTABLE VARIATION IS RELATIVE TO THE MAGNITUDE OF THE VALUE ITSELF. IN THIS CASE, THE TOLERANCE IS EXPRESSED AS A PERCENTAGE OF THE NOMINAL VALUE. FOR EXAMPLE, A RESISTOR WITH A VALUE OF 100 OHMS AND A TOLERANCE OF 5% WOULD HAVE AN ACCEPTABLE RANGE OF 95 OHMS TO 105 OHMS (5% OF 100 IS 5, SO 100 ± 5). THIS TYPE OF TOLERANCE IS USEFUL WHEN DEALING WITH VALUES THAT CAN VARY GREATLY IN MAGNITUDE, ENSURING THAT THE RELATIVE DEVIATION REMAINS CONSISTENT.

BILATERAL TOLERANCE

BILATERAL TOLERANCE ALLOWS FOR VARIATION IN BOTH THE POSITIVE AND NEGATIVE DIRECTIONS FROM THE NOMINAL VALUE. THIS IS TYPICALLY REPRESENTED AS A VALUE WITH BOTH AN UPPER AND LOWER DEVIATION, SUCH AS 25 MM $+0.1$ MM / -0.2 MM. THIS SIGNIFIES THAT THE ACTUAL DIMENSION CAN BE ANYWHERE BETWEEN 24.8 MM AND 25.1 MM. THIS IS A VERY COMMON FORM OF TOLERANCE IN ENGINEERING AND MANUFACTURING, PROVIDING A SYMMETRICAL OR ASYMMETRICAL RANGE FOR ACCEPTABLE DEVIATIONS.

UNILATERAL TOLERANCE

UNILATERAL TOLERANCE, IN CONTRAST TO BILATERAL, RESTRICTS THE VARIATION TO ONLY ONE DIRECTION FROM THE NOMINAL VALUE. THIS MIGHT BE SPECIFIED AS 30 MM $+0.5$ MM, MEANING THE DIMENSION CAN BE UP TO 30.5 MM BUT CANNOT BE LESS THAN 30 MM. ALTERNATIVELY, IT COULD BE 30 MM -0.3 MM, ALLOWING FOR VALUES DOWN TO 29.7 MM BUT NOT EXCEEDING 30 MM. THIS IS OFTEN USED WHEN ONE DIRECTION OF DEVIATION HAS MORE CRITICAL IMPLICATIONS THAN THE OTHER.

TOLERANCE IN MEASUREMENT AND ENGINEERING

THE APPLICATION OF TOLERANCE IN MEASUREMENT AND ENGINEERING IS PERHAPS ITS MOST WIDELY RECOGNIZED DOMAIN. IN THE

CREATION OF ANY PHYSICAL OBJECT, FROM A TINY SCREW TO A MASSIVE BRIDGE, PRECISION IS KEY, BUT ABSOLUTE PRECISION IS IMPOSSIBLE. ENGINEERS USE TOLERANCE TO DEFINE THE ACCEPTABLE LIMITS FOR DIMENSIONS, ANGLES, AND OTHER CHARACTERISTICS OF A PART OR ASSEMBLY. THIS ENSURES THAT COMPONENTS MANUFACTURED BY DIFFERENT PROCESSES OR EVEN IN DIFFERENT LOCATIONS CAN STILL FIT TOGETHER AND FUNCTION AS INTENDED.

FOR INSTANCE, WHEN TWO MATING PARTS ARE DESIGNED, SUCH AS A SHAFT AND A HOLE, ENGINEERS SPECIFY TOLERANCES FOR BOTH. IF THE SHAFT'S DIAMETER IS $10 \text{ mm} \pm 0.05 \text{ mm}$ AND THE HOLE'S DIAMETER IS $10.1 \text{ mm} \pm 0.05 \text{ mm}$, WE CAN BE CONFIDENT THAT THEY WILL FIT. THE TIGHTEST THE SHAFT CAN BE IS 9.95 mm , AND THE WIDEST THE HOLE CAN BE IS 10.15 mm , LEAVING A CLEARANCE. CONVERSELY, THE WIDEST THE SHAFT CAN BE IS 10.05 mm , AND THE TIGHTEST THE HOLE CAN BE IS 10.05 mm , INDICATING A POTENTIAL FOR A SNUG FIT BUT STILL WITHIN ACCEPTABLE LIMITS. THIS CAREFUL INTERPLAY OF TOLERANCES PREVENTS INTERFERENCE OR EXCESSIVE LOOSENESS, GUARANTEEING THE PROPER OPERATION OF MACHINERY.

THIS CONCEPT EXTENDS TO GEOMETRIC TOLERANCING, WHICH DEFINES NOT JUST THE SIZE BUT ALSO THE FORM, ORIENTATION, AND LOCATION OF FEATURES ON A PART. SYMBOLS ON TECHNICAL DRAWINGS SPECIFY ACCEPTABLE VARIATIONS IN FLATNESS, STRAIGHTNESS, PERPENDICULARITY, AND CONCENTRICITY, ENSURING THAT PARTS ARE NOT ONLY THE CORRECT SIZE BUT ALSO CORRECTLY ORIENTED RELATIVE TO EACH OTHER.

TOLERANCE IN NUMERICAL ANALYSIS AND COMPUTATION

BEYOND THE PHYSICAL REALM, TOLERANCE PLAYS A CRUCIAL ROLE IN NUMERICAL ANALYSIS AND COMPUTATIONAL MATHEMATICS. COMPUTERS OPERATE WITH FINITE PRECISION, MEANING THAT NUMBERS ARE REPRESENTED WITH A LIMITED NUMBER OF DIGITS. THIS LEADS TO ROUNDING ERRORS WHEN PERFORMING CALCULATIONS, ESPECIALLY WITH IRRATIONAL NUMBERS OR DIVISIONS THAT RESULT IN REPEATING DECIMALS.

IN ITERATIVE ALGORITHMS, WHICH REPEATEDLY REFINE A SOLUTION UNTIL A CERTAIN CONDITION IS MET, TOLERANCE IS USED TO DETERMINE WHEN THE PROCESS HAS CONVERGED SUFFICIENTLY. FOR EXAMPLE, WHEN SOLVING AN EQUATION NUMERICALLY, AN ALGORITHM MIGHT GENERATE A SEQUENCE OF APPROXIMATIONS. INSTEAD OF RUNNING INDEFINITELY, THE ALGORITHM STOPS WHEN THE DIFFERENCE BETWEEN SUCCESSIVE APPROXIMATIONS, OR THE DIFFERENCE BETWEEN THE CURRENT APPROXIMATION AND A KNOWN BENCHMARK, FALLS BELOW A PREDEFINED TOLERANCE VALUE. THIS INDICATES THAT THE SOLUTION HAS REACHED AN ACCEPTABLE LEVEL OF ACCURACY FOR PRACTICAL PURPOSES.

SIMILARLY, IN COMPARING FLOATING-POINT NUMBERS, DIRECT EQUALITY CHECKS (E.G., `'A == B'`) CAN BE UNRELIABLE DUE TO ROUNDING ERRORS. INSTEAD, MATHEMATICIANS AND PROGRAMMERS CHECK IF THE ABSOLUTE DIFFERENCE BETWEEN THE TWO NUMBERS IS LESS THAN A SMALL TOLERANCE (E.G., `'ABS(A - B) < EPSILON'`, WHERE EPSILON IS A SMALL TOLERANCE VALUE). THIS APPROACH ACKNOWLEDGES THE INHERENT IMPRECISION IN FLOATING-POINT ARITHMETIC AND PROVIDES A MORE ROBUST METHOD FOR DETERMINING IF TWO COMPUTED VALUES ARE EFFECTIVELY EQUAL.

TOLERANCE IN GEOMETRY AND DESIGN

IN GEOMETRIC MODELING AND COMPUTER-AIDED DESIGN (CAD), TOLERANCE IS ESSENTIAL FOR CREATING DIGITAL REPRESENTATIONS THAT CAN BE TRANSLATED INTO PHYSICAL OBJECTS OR USED FOR SIMULATIONS. WHEN DESIGNERS CREATE A 3D MODEL, THEY OFTEN WORK WITH IDEALIZED GEOMETRIC SHAPES. HOWEVER, WHEN THIS MODEL IS SENT TO MANUFACTURING, THE TOLERANCES INHERENT IN THE PRODUCTION PROCESS MUST BE CONSIDERED.

TOLERANCE IN GEOMETRIC DESIGN CAN INFLUENCE THE CREATION OF FEATURES LIKE FILLETS, CHAMFERS, AND COMPLEX CURVES. FOR EXAMPLE, A CURVE THAT APPEARS PERFECTLY SMOOTH IN A CAD MODEL MIGHT BE REPRESENTED BY A SERIES OF STRAIGHT LINE SEGMENTS OR A POLYNOMIAL APPROXIMATION IN ITS DIGITAL FORM. THE TOLERANCE USED IN THIS APPROXIMATION DETERMINES HOW CLOSELY THE DIGITAL REPRESENTATION MATCHES THE IDEAL CURVE. IF THE TOLERANCE IS TOO LARGE, THE CURVE MIGHT APPEAR JAGGED OR INACCURATE WHEN RENDERED OR MANUFACTURED.

FURTHERMORE, IN COMPUTATIONAL GEOMETRY, ALGORITHMS THAT DEAL WITH SHAPES OFTEN NEED TO ACCOUNT FOR SLIGHT

IMPERFECTIONS OR VARIATIONS. TOLERANCE IS USED TO DETERMINE WHEN TWO POINTS ARE "CLOSE ENOUGH" TO BE CONSIDERED THE SAME, OR WHEN A LINE SEGMENT IS "CLOSE ENOUGH" TO A CURVE TO BE TREATED AS PART OF IT. THIS ALLOWS FOR MORE ROBUST AND FORGIVING ALGORITHMS THAT CAN HANDLE REAL-WORLD DATA OR IMPERFECT MODELS.

CALCULATING AND EXPRESSING TOLERANCE

THE METHOD OF CALCULATING AND EXPRESSING TOLERANCE DEPENDS HEAVILY ON THE CONTEXT AND THE DESIRED LEVEL OF PRECISION. IN ENGINEERING, TOLERANCES ARE OFTEN DERIVED FROM FUNCTIONAL REQUIREMENTS, MANUFACTURING CAPABILITIES, AND COST CONSIDERATIONS. A CRITICAL DIMENSION THAT NEEDS TO ENSURE A PRECISE FIT WILL HAVE A TIGHTER TOLERANCE (SMALLER ALLOWABLE VARIATION) THAN A LESS CRITICAL DIMENSION.

THE EXPRESSION OF TOLERANCE CAN TAKE SEVERAL FORMS ON TECHNICAL DRAWINGS AND IN SPECIFICATIONS. COMMON METHODS INCLUDE:

- DIRECT NUMERICAL INDICATION: E.G., 25.00 ± 0.05 MM
- LIMIT DIMENSIONS: E.G., 24.95 - 25.05 MM
- TOLERANCED DIMENSIONS WITH UPPER AND LOWER DEVIATIONS: E.G., $25.00 +0.10 / -0.05$ MM
- GEOMETRIC TOLERANCING SYMBOLS: THESE SYMBOLS, COMBINED WITH NUMERICAL VALUES, SPECIFY ALLOWABLE VARIATIONS IN FORM, ORIENTATION, LOCATION, AND RUNOUT.

IN NUMERICAL ANALYSIS, TOLERANCE IS TYPICALLY A SMALL POSITIVE NUMBER, OFTEN DENOTED BY GREEK LETTERS LIKE EPSILON (ϵ). THE CHOICE OF THIS VALUE IS CRITICAL; TOO LARGE, AND THE SOLUTION MIGHT NOT BE ACCURATE ENOUGH; TOO SMALL, AND THE COMPUTATION MIGHT TAKE EXCESSIVELY LONG OR EVEN FAIL TO CONVERGE DUE TO MACHINE PRECISION LIMITS.

THE IMPORTANCE OF UNDERSTANDING TOLERANCE

ULTIMATELY, UNDERSTANDING TOLERANCE IN MATHEMATICS IS NOT JUST AN ACADEMIC EXERCISE; IT IS A PRACTICAL NECESSITY THAT UNDERPINS THE FUNCTIONALITY AND RELIABILITY OF COUNTLESS SYSTEMS AND PRODUCTS WE ENCOUNTER DAILY. FROM THE SMARTPHONE IN YOUR POCKET, ASSEMBLED WITH PARTS MANUFACTURED TO INCREDIBLY TIGHT TOLERANCES, TO THE AIRCRAFT YOU FLY IN, WHERE EVERY COMPONENT'S PRECISION IS CRITICAL FOR SAFETY, THE CONCEPT OF ACCEPTABLE VARIATION IS PARAMOUNT.

WITHOUT A CLEAR UNDERSTANDING AND APPLICATION OF TOLERANCE, ENGINEERING DESIGNS WOULD BE IMPOSSIBLE TO MANUFACTURE, SCIENTIFIC EXPERIMENTS WOULD YIELD UNRELIABLE DATA, AND COMPUTATIONAL RESULTS WOULD BE SUSPECT. IT ALLOWS US TO BRIDGE THE GAP BETWEEN THEORETICAL PERFECTION AND THE IMPERFECTIONS OF THE REAL WORLD, ENABLING US TO CREATE, MEASURE, AND COMPUTE WITH CONFIDENCE. EMBRACING TOLERANCE MEANS ACKNOWLEDGING LIMITATIONS WHILE STILL STRIVING FOR ACCEPTABLE PERFORMANCE, A CRUCIAL BALANCE IN BOTH MATHEMATICAL AND PRACTICAL ENDEAVORS.

IT EMPOWERS US TO MAKE INFORMED DECISIONS ABOUT THE LEVEL OF PRECISION REQUIRED FOR A GIVEN TASK, OPTIMIZING FOR BOTH PERFORMANCE AND COST-EFFECTIVENESS. WHETHER YOU'RE A STUDENT LEARNING ABOUT MEASUREMENT, AN ENGINEER DESIGNING A NEW PRODUCT, OR A PROGRAMMER DEVELOPING AN ALGORITHM, THE PRINCIPLES OF TOLERANCE WILL INVARIABLY GUIDE YOUR WORK TOWARD SUCCESSFUL AND MEANINGFUL OUTCOMES.

FAQ

Q: WHAT IS THE DIFFERENCE BETWEEN TOLERANCE AND ACCURACY IN MATHEMATICS?

A: ACCURACY REFERS TO HOW CLOSE A MEASUREMENT OR CALCULATION IS TO THE TRUE OR ACCEPTED VALUE. TOLERANCE, ON THE OTHER HAND, DEFINES THE ACCEPTABLE RANGE OF DEVIATION FROM A SPECIFIED VALUE. A MEASUREMENT CAN BE INACCURATE BUT STILL WITHIN ITS SPECIFIED TOLERANCE, OR IT CAN BE ACCURATE BUT OUTSIDE ITS TOLERANCE IF THE TARGET VALUE ITSELF WAS INCORRECT.

Q: HOW DO YOU CHOOSE AN APPROPRIATE TOLERANCE VALUE?

A: CHOOSING AN APPROPRIATE TOLERANCE VALUE DEPENDS ON SEVERAL FACTORS, INCLUDING THE FUNCTION OF THE PART OR MEASUREMENT, THE PRECISION OF THE MANUFACTURING OR MEASUREMENT TOOLS AVAILABLE, COST CONSTRAINTS, AND SAFETY REQUIREMENTS. TIGHTER TOLERANCES GENERALLY LEAD TO HIGHER COSTS DUE TO MORE PRECISE MANUFACTURING PROCESSES.

Q: IS TOLERANCE ONLY USED IN ENGINEERING?

A: NO, WHILE TOLERANCE IS HEAVILY USED IN ENGINEERING AND MANUFACTURING, IT'S ALSO CRUCIAL IN OTHER FIELDS. IN NUMERICAL ANALYSIS AND COMPUTER SCIENCE, TOLERANCE IS USED TO DETERMINE WHEN NUMERICAL SOLUTIONS ARE SUFFICIENTLY CLOSE TO THE TRUE SOLUTION OR WHEN FLOATING-POINT NUMBERS ARE CONSIDERED EQUAL. IT'S ALSO RELEVANT IN SCIENTIFIC EXPERIMENTATION FOR DATA ANALYSIS.

Q: CAN TOLERANCE BE APPLIED TO ABSTRACT MATHEMATICAL CONCEPTS?

A: YES, IN AREAS LIKE THEORETICAL MATHEMATICS, PARTICULARLY IN FIELDS THAT DEAL WITH APPROXIMATIONS OR CONVERGENCE, TOLERANCE-LIKE CONCEPTS CAN BE APPLIED. FOR INSTANCE, IN DEFINING LIMITS OR CONVERGENCE OF SEQUENCES, A SIMILAR IDEA OF BEING "ARBITRARILY CLOSE" TO A VALUE IS USED, WHICH IS CONCEPTUALLY RELATED TO TOLERANCE.

Q: WHAT HAPPENS IF A MEASUREMENT OR VALUE IS OUTSIDE ITS SPECIFIED TOLERANCE?

A: IF A MEASUREMENT OR VALUE FALLS OUTSIDE ITS SPECIFIED TOLERANCE, IT IS GENERALLY CONSIDERED NON-CONFORMING OR DEFECTIVE. IN MANUFACTURING, THIS MIGHT MEAN THE PART IS REJECTED. IN SCIENTIFIC EXPERIMENTS, IT MIGHT INDICATE AN ERROR IN THE PROCEDURE OR EQUIPMENT, OR THAT THE RESULT IS NOT STATISTICALLY SIGNIFICANT. IN COMPUTATION, IT COULD MEAN AN ALGORITHM HAS NOT CONVERGED OR THAT A COMPARISON BETWEEN NUMBERS IS NOT VALID.

Q: HOW IS TOLERANCE REPRESENTED ON TECHNICAL DRAWINGS?

A: TOLERANCE IS REPRESENTED ON TECHNICAL DRAWINGS USING VARIOUS NOTATIONS, INCLUDING PLUS-AND-MINUS VALUES (E.G., 10.0 ± 0.1 MM), LIMIT DIMENSIONS (E.G., $9.9 - 10.1$ MM), OR THROUGH THE USE OF GEOMETRIC TOLERANCING SYMBOLS THAT SPECIFY ALLOWABLE VARIATIONS IN FORM, ORIENTATION, AND LOCATION.

[Tolerance In Math](#)

Tolerance In Math

Related Articles

- [umd math courses](#)
- [the hardest game on earth math playground](#)
- [ucsd math econ](#)

[Back to Home](#)